





TYPE D AND E BACKFILL DETAILS

NOTES:

ف

- For HMA shoulders only, extend top layer of HMA placed on the shoulder under dike with no joint at the ES. For projects with OGFC shoulders, do not extend OGFC under dike. See project plans for modified dike detail.
- 2. Case R applies to retrofit only projects where restrictive conditions do not provide enough width for Case F backfill.
- 3. Type A dike only to be used where restrictive slope conditions do not provide enough width to use Type D or Type E dike.
- 4. Fill and compact with excavated material to top of dike.
- Use Type A or F dike, where dike is required with guardrail installations. See Standard Plan A77N4 for dike positioning details. See Standard Plan A77N3 for hinge point offsets with guardrail.

DIKE QUANTITIES

	CUBIC YARDS
TYPE	PER LINEAR FOOT
Α	0.0135
С	0.0038
D	0.0293
E	0.0130
F	0.0066

Quantities based on 5% cross slope.

STATE OF CALIFORNIA DEPARTMENT OF TRANSPORTATION

HOT MIX ASPHALT DIKES

NO SCALE

A87B